

## **Get It Done S5: Episode 9 Instructions**

### **Bathroom Cabinet**

#### **Tools**

Jig Saw  
PSR 18 volt Cordless drill  
PSR 10.8 volt cordless  
PSR 14.4 Cordless drill driver  
Dremel cordless driver  
Dremel Trio

#### **Material list**

Melamine 16mm Harvard Cherry (same colour edging)  
900 x 450mm - 2 pieces (edged 2 x long + 1 short edge)  
600 x 450 mm - 1 piece (edged all sides)  
568 x 450mm - 3 pieces (edged 1 long side for all three)  
568 x 70mm - 1 piece (no edging)  
500 x 296mm - 3 pieces (Edged all sides)  
Masonite 3 mm. 600 x 500 - 1 piece  
Plastic corner brackets (brown - 2 x 2 hole) you should find these by the section where all the cupboard hinges etc are.  
Plastic screw covers to match the wood colour  
4 x cantilever hinges  
Glass 3 or 4mm frosted with edges sanded and corners rounded. 2 pieces 176 x 380mm  
Plastic glass holders  
4 x 40 screws  
3 x 12mm screws  
Extra edging iron on 5 meters

#### **Steps**