

## **Get It Done S5: Episode 8 Instructions**

### **Ottoman Bench and Cover lid**

#### **Tools**

Jig Saw  
PLS 300 Jig saw guide  
PST 18volt Cordless Jig saw  
PSR 10.8 cordless screw driver  
PSR 14.4 Cordless Drill driver  
PEX 220 Eccentric sander  
PFS spray gun  
Dremel Trio plus router bits

#### **Material list**

Supa wood 16mm  
800 x 400mm - 2 pieces  
800 x 384mm - 2 pieces  
368 mm x 384mm - 2 pieces  
cleats 20 x 20mm  
4 x 40mm screws  
imbuia/dark mahogany wood filler  
Stain/varnish - dark mahogany  
Sponge to fit top 800 x 400 mm  
Material to cover

#### **Steps**

Stain Li  
Measure Mark and Drill Pilot Holes  
Assemble With Screws  
Varnish  
Upholster Lid